



MPB+ LASER CARVING
Pushbutton switches

▼ **LASER CARVING OPTIONS**

Note: Only available for metal switches - MPB19, MPB22, MPB25 series, please contact sales representative for full part number.

						RESET
L01	L02	L03	L04	L05	L06	L07
L08	L09	L10	L11	L12	L13	L14
				FM	START	OFF
L15	L16	L17	L18	L19	L20	L21
ON	UP	DOWN				
L22	L23	L24	L25	L26	L27	L28
			SOS	上升	下降	STOP
L29	L30	L31	L32	L33	L34	L35
OPEN	CLOSE	END	故障	暫停	急停	
L36	L37	L38	L39	L40	L41	L42
L43	L44	L45	L46	L47	L48	