

相识在隆瑞，做永远的朋友！

Acquaintance in Longrui, be permanent friends!



我们不仅给您提供价格，而且给您提供质量、服务和未来的业务前景

We are not only offering you the price also We are offering you the quality

Services and future business prospects

济宁隆瑞机械有限公司
Jining Longrui Machinery Co., Ltd.



隆瑞官网 LongRui Web



配件商城 Parts Mall



LongRui Alibaba

地址：山东济宁高新区第十一工业园

Add: High-tech Zong, Eleventh Industrial Park, Jining city, Shandong, China

电话 (Tel): 0086-537-3161898 E-mail: longruijixie@gmail.com

<https://www.longruiparts.com>

<https://www.longruijixie-mall.com>

<https://jnlrjx.en.alibaba.com>

为客户提供工程机械配件全套解决方案

Providing customers with a full-engineering machinery parts solution

让您的设备拥有更持久的生命力

Let your equipment have more lasting vitality



企业简介

Enterprise introduction

LONGRUI
济宁隆瑞机械有限公司

目录 CONTENTS

挖掘机配件

Excavator Parts

- 电器系统 Electrical System
- 发动机及相关部件 Engine & Related Parts
- 液压件 Hydraulic System
- 驾驶室及配件 Cabin & Parts
- 空调零件 Air conditioner parts
- 冷却系统 Cooling System
- 工作装置 Work Equipment
- 护罩和门 Work Equipment
- 矿山机械底盘件 Mining machinery parts
- 过滤器 filters
- 服务套件&密封件 Service kit and Seals
- 螺栓螺母 Bolt and Nut

推土机

Bulldozer Parts

自卸车配件

Dump trucks parts

轮式装载机配件

Wheel loader parts

水平定向钻机

Horizontal Directional Drill

济宁隆瑞机械有限公司坐落于山东省济宁高新区第十一工业园，是专业从事工程机械、矿山机械，销售、零部件供应；筑养路及养护机械设备研发、生产、销售、技术支持、服务咨询为一体的专业化公司。

济宁隆瑞机械有限公司以山东济宁工程机械制造基地为运营中心，主营业务：筑养路、养护机械设计、生产、销售；二手工程机械翻新再制造；专业生产履带式工程机械底盘件及金属结构件等产品。

我司与多家小松OEM工厂和集团旗下的大型仓库合作，致力于为多个品牌的挖掘机、推土机、装载机和矿山机械，提供更高标准的服务，提供最具竞争力的零配件价格。

济宁隆瑞机械有限公司成立于2014年，公司主营小松（KOMATSU）、山推（SHANTUI）、卡特（CAT）等国际知名品牌的全系列产品的配件。公司目前已拥有固定代理商和客户上万家，业务现已覆盖全球120多个国家和地区。

Jining Longrui Machinery Co., Ltd., which is located in High-tech zone, Eleventh industrial Park, Jining City, Shandong Province, is a company specialized in sales of construction machinery, spare parts supply, the development and sale of Road Building maintenance machinery and the sale of mini skid steer loader. And the company sets technical support and consulting services as a whole.

Jining Longrui Machinery Co., Ltd., with the operation center of Shandong Jining Engineer Machinery Manufacturing Base, main business: the design and sales of Road Building maintenance machinery; Used Engineering & Construction Machinery Remanufacturing. Specializing in the production of tracked

construction machinery chassis components and metal structural components, Cooperated with multiple Komatsu OEM factories and huge warehouse under, we are dedicated to strive for a higher standard of service in providing GENUINE and OEM parts for Excavators, Bulldozers, Loaders and Mining Machineries of multiple Brands, offering the most competitive price at stock.

Jining Longrui Machinery Co., Ltd. was established in 2014. The company is mainly engaged in accessories for a full range of products of international famous brands such as KOMATSU, SHANTUI and CAT. At present, the company has tens of thousands of fixed agents and customers, and its business now covers more than 120 countries and regions around the world.

相识在隆瑞 做永远的朋友——是隆瑞的经营理念

Acquaintance in Longrui, be permanent friends! -The Management idea of longrui



挖掘机配件 Excavator Parts

电器系统 Electrical System



监控器 PC300-8M0 MONITOR
7835-34-1002 1003



控制器 PC200-8 CONTROLLER
7835-46-1010



先导阀 PILOT VALVE
702-21-57500



电磁阀 78US-5 SOLENOID VALVE
201-60-72110



电磁阀 SOLENOID
22B-62-45811



电磁阀 SOLENOID
20Y-60-32121



电阻器 RESISTOR
7861-94-2000



电阻器 RESISTOR
7861-94-3000



收音机 RADIO
20Y-06-41238 22730 42430



收音机 RADIO
20Y-06-22730 20Y-06-41239



喇叭 PC300-7 D475A-5
HORN 20Y-06-D1370 D1360



喇叭 PC200-8 HORN
08160-72400 08160-72420

电器系统 Electrical System

挖掘机配件 Excavator Parts



喇叭 PC300-8M0 HORN
20Y-06-42810 20Y-06-42820



开关 STARTING SWITCH
22B-06-11910



开关 SWITCH HEATER
600-815-2170



开关SWITCH ASS'Y
22U-06-22370



开关 SWITCH ASS'Y
20Y-06-41151



开关 SWITCH
206-06-61130



开关 SWITCH ASS'Y
22U-06-22360



阀组 PC55MR-3 PC45MR-3
VALVE ASS'Y 22F-60-31600



阀组 PC78US-8 VALVE ASS'Y
22P-60-12112



阀组 PC200-7 VALVE ASS'Y
20Y-60-31212



阀组 PC200-8 VALVE ASS'Y
20Y-60-41621



阀组 PC300-7 VALVE ASS'Y
207-60-71311 2A8-60-11420



阀组 PC400-6 VALVE ASS'Y
206-60-51102



阀组 PC800-8 SOLENOID ASS'Y
209-60-41310



阀组 PC1250-8 VALVE ASS'Y
209-60-77240



灯总成 PC200-8M0
WORKING LAMP ASS'Y



灯 PC228USLC-3 PC138 WORK
LAMP ASS'Y 22B-54-17511



灯 PC360-7 WORK LAMP
20Y-06-D1390



灯 PC600-8 WORK LAMP ASS'Y
21N-54-38340



灯 PC600-8 WORK LAMP ASS'Y
209-53-14430

挖掘机配件 Excavator Parts

电器系统 Electrical System



灯 HD785-7 WORKING LAMP
21T-06-33930



灯 PC200-8 WORK LAMP
20Y-53-15210



传感器 PC210-10 SENSOR
729-12-21000



传感器 SENSOR PC200-8M0
7861-93-1430



传感器 SENSOR
7861-93-1840



传感器 SENSOR
7861-93-1880



传感器 WA800-3E0 SENSOR
7861-93-3520



传感器 HD785-7 PRESSURE SENSOR
7861-93-1653



传感器 PC200-7 REVOLUTION
SENSOR 7861-93-2310



传感器 PC200-8 SENSOR
20Y-979-6161



传感器 PC650-8M0 TEMPERATURE
SENSOR 7861-93-3520



传感器 PC1270-7 SENSOR
7861-93-5810



传感器 PC2000-8 OIL TEMPERATURE
SENSOR 7861-93-3500




传感器 SAA6D140E-3 BOOST
PRESSURE SENSOR 6217-81-9240



传感器 SENSOR
7861-92-2310



传感器 SENSOR
7861-93-1890



传感器 油箱 SENSOR
7861-92-5810



继电器 PC130-7 RELAY
198-911-9240



继电器 PC200-8 RELAY
20Y-979-6771




继电器 RELAY
08088-70000

电器系统 Electrical System

挖掘机配件 Excavator Parts



继电器 RELAY
600-815-8941



继电器 RELAY
7861-74-5100



线束 PC200-8 WIRING HARNESS
20Y-06-42411 X990306043



线束 PC300-7 WIRING HARNESS
207-06-71110



线束 PC300-8 WIRING HARNESS
20Y-06-41141



线束 PC300-8 WIRING HARNESS
20Y-06-42320



线束 PC350-8 PC400-8 WIRING
HARNESS 20Y-06-41121 21M-06-31170



线束 PC400-8 WIRING HARNESS
208-06-76831 X211263768



线束 PC1250-7 WIRING HARNESS
21N-06-33310



线束 PC130US-8 WIRING HARNESS
6271-81-8212 6271-81-8240



线束 PC200-7 WIRING HARNESS
20Y-06-31614 31613



线束 PC200-7 WIRING HARNESS
20Y-06-71512



线束 PC200-8 6AA6D107E WIRING
HARNESS 6754-81-9310



线束 PC200-8 WIRING HARNESS
20Y-06-41130



线束 PC200-8M0 WIRING
HARNESS 20Y-06-16920



线束 PC200-8M0 WIRING HARNESS
6754-81-9520



线束 PC200-8M0 PC700LC-8E0
WIRING HARNESS 20Y-06-16910



线束 PC210-10 WIRING HARNESS
20Y-06-41161



线束 PC300-7 WIRING HARNESS
20Y-54-52320



线束 PC300-7 WIRING HARNESS
207-06-71562



灯线束 PC300-7 WIRING HARNESS
20Y-54-52310



线束 PC300-7 WIRING HARNESS
207-06-71114



线束 PC300-7 WIRING HARNESS
207-06-71211



线束 PC300-7 WIRING HARNESS
6743-81-8310



线束 PC300-8 WIRING HARNESS
207-06-76130



线束 PC300-8 WIRING HARNESS
6745-81-9230



线束 PC300-8M0 WIRING HARNESS
207-06-77411



线束 PC350-7 WIRING HARNESS
207-06-71161



线束 PC350-7 WIRING HARNESS
207-06-71141



线束 PC400-7 WIRING HARNESS
6156-81-9320



线束 PC400-7 SAA6D140E-3 WIRING
HARNESS 207-06-71170



线束 PC400-7 WIRING HARNESS
6156-81-9211



线束 PC400-8 WIRING HARNESS
208-06-71113



线束 PC400-8 WIRING HARNESS
208-06-71510 71511



线束 PC400-8 WIRING HARNESS
6251-81-9810



线束 PC600-8 WIRING HARNESS
208-979-7550



线束 PC800-7 WIRING HARNESS
6218-81-8722



线束 PC800-7 WIRING HARNESS
6218-81-8310



线束 PC1250-7 WIRING HARNESS
21N-06-33222



线束 WA380-6 WIRING HARNESS
423-06-42230



发动机套餐 PC200-8M0 ENGINE
REPAIR KIT PC200-8ENG0V



发动机套餐 PC300-7 ENGINE
GASKET KIT PC300-7ENG0V1



衬垫 SA12V140 HEAD GASKET
6210-17-1814



衬垫 PC400-8 HEAD GASKET
6251-11-1810



维修套件 PC300-7 GASKET KIT
6743-K1-1100



维修套件 PC300-7 GASKET
KIT 6743-K2-1100



维修套件 PC400-7 GASKET KIT
6159-K2-9900



维修套件 PC400-7 GASKET KIT
6159-K1-9900



维修套件 PC200-8M0 GASKET KIT
1078-KIT-1



阀 SA12V140-1 SAA6D170E-2
VALVE 600-815-7581



泵 FUEL PUMP
6745-71-1840



泵 200-8 PUMP
6754-72-1020



机油泵 PC300-7 OIL PUMP ASS'Y
6741-51-1110



机油泵 PC400-8 OIL PUMP
6251-51-1001



水泵 PC400-7 WATER PUMP
6154-61-1102



水泵 PC400-8 WATER PUMP ASS'Y
6251-61-1101



机油泵 SAA12V140E-3 OIL
PUMP 6219-51-1000



加热开关 SAA6D170E-3
HEATER SWITCH 600-815-2690



3轴 SAA6D170E SHAFT
6150-21-2411



轴 SAA6D170E-3 SHAFT
6240-61-4251



燃油歧管PC200-8 FUEL MANIFOLD
6754-71-1210



燃油歧管 PC300-8 PC350-8 FUEL
MANIFOLD 6745-71-4310



喷油器 PC200-8 INJECTOR ASS'Y
6754-11-3011



喷油器 PC300-8 INJECTOR ASS'Y
6745-12-3100



喷油器 PC300-7 INJECTOR ASS'Y
6743-11-3320



喷油器 PC400-7 INJECTOR ASS'Y
6156-11-3300



喷油器 PC400-8 INJECTOR ASS'Y
6251-11-3100



喷油器 EC210B D6E INJECTOR
ASS'Y 0445120067



喷油器 CAT C30 INJECTOR ASS'Y
232-1167



喷油器 320D2 C7.1 INJECTOR
ASS'Y 371-3974



喷油器 CAT 3114 INJECTOR ASS'Y
4P-2995



喷油器 CAT C-9 336D INJECTOR
ASS'Y 235-2888



喷油器 INJECTOR ASS'Y
0445110454



喷油器 CUMMINS QSM11 INJECTOR
ASS'Y 4903472




传感器 PC200-8 PRESSURE SENSOR
6754-72-1210




传感器 PC300-8 LEVEL SENSOR
6741-81-9220



传感器 PC400-8 SENSOR ASS'Y
ND949979-1300



管路 PC2000-8 SAA12V140E-3
TUBE 6219-71-7110



管路 PC2000-8 SAA12V140E-3
TUBE 6219-11-6510



连接器 PC400-8 CONNECTOR
6251-11-5510



弹簧 PC130-7 SPRING
203-43-62121



弹簧 PC200-7 SPRING ASS'Y
20Y-43-23442



弹簧 PC360-7 SPRING
207-43-74120



弹簧 SAA6D170E-3 SPRING
600-211-1870



线束 PC300-8 WIRE HARNESS
6745-81-9240



线束 PC200-8 WIRE HARNESS
6754-81-9450



线束 PC200-8 WIRE HARNESS
6754-81-9210



线束 PC400-8 WIRING HARNESS
6156-81-9110



IMV 阀 PC200-8 VALVE (imv)
6754-71-4100



IMV 阀 PC300-8 VALVE (imv)
0928400473



发动机垫 PC200-8 CUSHION
20Y-01-12210



发动机垫 PC200-8 CUSHION
20Y-01-12222



发动机垫 PC300-8 CUSHION
208-01-55220



发动机垫 PC2000-8 CUSHION
21N-01-11120



盖 SAA6D140E-3 SAA6D170E-3
OIL FILLER CAP 07025-00100



盖 PC56-7 CAP
22H-03-11410



盖 PC200-8 CAP
20Y-03-22110



燃油供应管 D155 SAA6D140E-5
ENGINE INJECTION TUBE
6261-71-5113



燃油供应管 HD785 SAA12V140E-3
ENGINE INJECTION TUBE
6219-71-4111 6219-71-4211



燃油供应管 SAA6D170E-5
ENGINE INJECTION TUBE
6245-71-5111

液压件 Hydraulic System



主泵 PC60-8 MAIN PUMP
708-3T-00151



阀总成 PC70-8 VALVE ASS'Y
723-26-50900 723-28-51500



阀总成 PC2000-8 VALVE ASSEMBLY
209-60-77220



阀总成 PC2000-8 VALVE ASSEMBLY
209-60-77230



阀总成 PC200-6 VALVE ASS'Y
702-21-09147



阀总成 PC2000-11 VALVE
21N-60-51210



先导阀 PC300-8 PILOT VALVE
702-16-03910



阀总成 PC200-8 VALVE ASS'Y
723-40-71900



阀体 PC300-7 VALVE
207-60-71311



先导阀 PC200-8 PILOT VALVE
702-21-57400



阀体 PC200-7 VALVE
20Y-60-31211



蓄能器 PC200-8 ACCUMULATOR
22U-60-21330



蓄能器 PC1250-8 ACCUMULATOR
20Y-60-11431



蓄能器 PC2000-8 ACCUMULATOR
21T-64-33840



齿轮 PC60-8 GEAR
TZ110D1004-00



齿轮 PC130-8 GEAR
203-26-61150



齿轮 PC1250-8 GEAR
208-26-71151



轴 PC60-8 SHAFT
TZ110D2002-00



立轴 PC130-8 SHAFT
203-26-61220



立轴 PC200-7 SHAFT
22U-26-21560

液压件 Hydraulic System



立轴 PC220-8 SHAFT
206-26-73130



立轴 PC300-8 SHAFT
207-26-62180



摩擦板 300-8 PLATE
706-7K-91340



摩擦板 PC300-8 PLATE
708-8H-35130



磨擦片 PC300-8 DISC
708-8H-35180



磨擦片 400-8 DISC
706-7K-91350



旁通阀 PC200-8 VALVE ASS'Y
20Y-60-31131



旁通阀 PC228USLC-10 VALVE ASS'Y
20Y-60-31450



旁通阀 PC400-8 VALVE ASS'Y
208-60-71160



油位计 PC300-8 TUBE
203-60-31160



减速机盖 200-8 SPROCKET COVER
20Y-27-41160



减速机盖 PC210-10 PROCKET COVER
20Y-27-42190



减速机盖 PC210-11 SPROCKET COVER
20Y-27-42530



减速机盖 PC350-8 COVER
207-27-71340



减速机盖 PC360LC-10 SPROCKET COVER
207-27-72180



减速机盖 PC450-8 COVER
208-27-71183



减速机盖 PC500LC-10M0 COVER
2A8-27-11190



行走轮轂 PC200-8 HUB
20Y-27-41140



行走轮轂 PC200-8 HUB
20Y-27-42520



行走轮轂 PC220-8 HUB
22U-27-21182

挖掘机配件 Excavator Parts

液压件 Hydraulic System



行走轮毂 PC300-8 HUB
207-27-71311



行走轮毂 PC300-8M0 HUB
207-27-72290



主泵缸体 PC200-8 BLOCK ASS'Y
708-2L-06470 708-2L-06480



主泵缸体 PC300-7 CYLINDER BLOCK
ASS'Y 708-2G-04141



主泵支撑 PC200-8 CRADLE ASS'Y
708-2L-06630



主泵支撑 PC300-7 CRADLE SUB
ASSY 708-2G-04161



主泵盘 PC300-7 BLOCK ASS'Y
708-2G-04153



主泵盘 PC300-7 SHOE RETAINER
708-2G-13341



主泵柱塞 PC200-8 PISTON SUB ASS'Y
708-2L-33430



主泵柱塞 PC300-7 PISTON SUB
ASS'Y 708-2G-13311



浮动油封 PC270-8 FLOATING
SEAL 207-27-72220



主泵阀块 PC200-8 BLOCK
20Y-62-52790



主泵盘 PC200-8 SHOE RETAINER
708-2L-33350



主泵销 PC300-7 PIN
708-2H-23360



浮动油封 PC300-7 FLOATING SEAL
207-27-00420



浮动油封 PC300-8 FLOATING SEAL
207-27-00510



盖 PC200-8 CAP ASS'Y
17A-60-11310



盖 PC490-11 CAP ASS'Y
207-60-21220



阀总成 PC300-7 VALVE
ASS'Y 207-03-71290



阀总成 PC1250-8 VALVE
ASSEMBLY 209-60-77310

驾驶室及配件 Cabin & Parts

挖掘机配件 Excavator Parts



减震器 PC300-7 PC400-7
CUSHION 20Y-54-65821



减震器 PC200-8 CUSHION
20Y-53-13121 20Y-53-13113



电位计 PC300-7 POTENTIOMETER
22U-06-22420



电位计 PC300-8 POTENTIOMETER
22U-06-22380



开关 PC200-8 SWITCH
20Y-06-42110



开关 BUZZER SWITCH
22U-06-22190



开关 LAMP SWITCH
20Y-06-42450 42121



开关 PC300-7 SWITCH
22U-06-22290



开关 PC300-7 SWITCH
22U-06-22390



开关 SWITCH
22U-43-21211



地板垫 PC200-6 PC400-6
FLOOR MAT



地板垫 PC200-8 MAT
20Y-53-14723



地板垫 PC200-8M0 FLOOR
MAT 20Y-43-15751



地板垫 PC1250-7 FLOOR MAT
20Y-54-65610



风道 PC300-8M0 DUCT
20Y-53-13361



风道 PC210-10 DUCT
2A5-979-1211



风道 PC300-8 DUCT
2A5-979-1231



风道 PC300-8 DUCT
20Y-53-13381 20Y-53-13371



风道 PC300-8M0 DUCT
2A5-979-1241



风道 PC300-8M0 DUCT
20Y-53-13351

挖掘机配件 Excavator Parts

驾驶室及配件 Cabin & Parts

			
盖 PC400-7 PC200-7 KNOB 22U-06-22470	盖 PC300-8 COVER 20Y-43-41323	盖 PC200-8 PC350-8 COVER 20Y-53-12122	盖 PC300-8 COVER 20Y-53-12381
			
盖 PC78UU-6 COVER 22U-43-23230	盖 PC200-8 COVER 20Y-43-41453	盖 PC300-7 COVER 208-43-71680 208-43-71690	盖 PC300-7 PC350-7 COVER 208-53-13620
			
盖 PC400-7 COVER 208-979-7961	盖 PC650-8 COVER 20Y-54-65580	格栅 PC300-8 GRILLE 208-979-7560	格栅 PC300-8 GRILLE 20Y-53-12172 20Y-53-12240
			
格栅 PC300-8 PC850-8 GRILLE 421-07-33870	格栅 PC360-7 D475A-5A GRILLE 201-979-7820	格栅 PC400-6 HD465-7 GRILLE 20Y-979-2161	水壶 PC78US-6 TANK 21W-06-42130
			
水壶 PC300-8 TANK ASS'Y 21T-06-11350	天线 PC1250-7 D85EX RUBBER ANTENNA 198-Z11-4610	雨刮电机 PC650-8 PC1250-8 WIPER MOTOR 21N-53-31270	点烟器 CIGARETTE LIGHTER 20Y-06-23472

空调零件 Air conditioner parts

挖掘机配件 Excavator Parts

			
空调总成 PC200-7 AIR CONDITIONER 208-979-7610	空调总成 PC210-10 AIR CONDITIONER 2A5-979-1113	空调总成 PC200-8 AIR CONDITIONER 20Y-810-1211	空调总成 PC1250-8 AIR CONDITIONER 20Y-979-6111
			
鼓风机 HD785 BLOWER INTAKE ASS'Y 561-07-81201	压缩机 PC200-8 COMPRESSOR ASS'Y 20Y-979-6121 20Y-810-1260	压缩机 PC1250-8 D375 COMPRESSOR ASS'Y 14X-911-7112	压缩机 PC70-8 WA320-6 COMPRESSOR ASS'Y 423-S62-4330
			
控制器 PC60-8 CONTROLLER ASS'Y 201-979-8960	控制器 PC200-7 PANEL ASS'Y 208-979-7630	控制器 PC200-8 CONTROLLER ASS'Y 17A-979-3180	控制器 PC300-8MO CONTROLLER ASS'Y 2A5-979-1121
			
冷凝器 HM300 HM400 CONDENSER ASS'Y 56E-07-21133	冷凝器 PC1250-7 CONDENSER ASS'Y 20Y-979-6131	冷凝器 PC60-8 CONDENSER ASS'Y 201-979-8850	冷凝器 PC200-8 CONDENSER ASS'Y 20Y-810-1221
			
暖风水箱 PC300-7 PC350-8 HEATER CORE SUB ND116140-0051	暖风水箱 PC200-8M0 D375A-8 HEATER CORE SUB ND116420-7450	暖风水箱 P1250-7 HEATER CORE SUB ND116120-7990	蒸发箱 PC200-8 EVAPORATOR ND446600-0991

挖掘机配件 Excavator Parts

空调零件 Air conditioner parts



蒸发箱 PC210-10 EVAPORATOR
ND447610-0630



风扇电机 PC200-8 D155AX-6 FAN
MOTOR ND116340-7350



风扇电机 PC200-8M0 D155AX-8 FAN
MOTOR ND116360-0030



风扇电机 PC200-7 PC2000-8
FAN MOTOR ND116340-7030



干燥瓶 PC60-8 PC70-8 RECEIVER
DRYER 22L-979-2232



干燥瓶 PC360-7 360-8 RECEIVER
DRYER 20Y-979-3120



热敏电阻 PC210-10 THERMISTOR
ND100775-8400



膨胀阀 PC210-10 PC220-8M0
EXPANSION VALVE ND447500-3750



恒温器 PC360-7 WA600-6
THERMOSTAT ND113550-0780



晶体管 PC300-8 POWER
TRANSISTOR ND077800-0750



空调管路 PC400-7 HOSE
208-979-7321 7351 7341 7331



空调管路 PC300-7 HOSE
207-979-7322 7353 7343 7331



空调管路 PC130-7 HOSE
203-979-7211 203-979-7241
203-979-7221 203-979-7231



空调管路 PC200-7 HOSE
20Y-979-6531 20Y-979-6561
20Y-979-6660 20Y-979-6551



空调管路 PC200-8M0 HOSE
20Y-810-1141
1720 1321 1710 1311



暖风管 PC200-8 HOSE
20Y-810-1332 20Y-810-1342



暖风管 PC300-8 HOSE
207-979-7930 207-979-7940



暖风管 PC400-8 HOSE
208-810-1332 208-810-1342



暖风管 PC650LC-8E0 HOSE
21M-979-3150 21M-979-3160



暖风管 PC850SE-8 HOSE
209-979-4151 209-979-4161

冷却系统 Cooling System

挖掘机配件 Excavator Parts



扇叶 PC200-8 COOLING FAN
600-625-7520



扇叶 PC300-8 COOLING
FAN 600-635-7870



扇叶 PC650LC-8E0 COOLING
FAN 600-645-7120



扇叶 PC850-8 FAN, COOLING
600-645-8400



油冷却器 PC200-8 OIL COOLER
208-03-71161



水壶 PC200-8 RESERVOIR
TANK 20Y-06-15240



水壶 PC300-8 RESERVOIR TANK
419-03-21320



水壶 PC1250-8 RESERVOIR
TANK 21N-03-31491



软管 PC2000-8 RADIATOR HOSE
21T-03-31391



软管 PC2000-8 D375A-6
RADIATOR HOSE 195-03-64441



软管 PC2000-8 PC1250-8
RADIATOR HOSE 195-03-64451



软管 PC1250-8 D155A-6
RADIATOR HOSE 209-03-41711



软管 PC2000-8 GD705A
RADIATOR HOSE 07260-04750



软管 PC2000-8 PC2000-11
RADIATOR HOSE 21T-03-32430



软管 PC1250-8 RADIATOR HOSE
21N-03-41731



软管 PC2000-8 GD705A
RADIATOR HOSE 21N-03-41741



软管 PC2000-8 PC1250-8
RADIATOR HOSE 209-03-41340



软管 PC1250-8 PC850-8 RADIATOR
HOSE 209-03-41330



软管 PC1250-8 PC850-8 RADIATOR
HOSE 209-03-42421



软管 PC1250-8 PC850-8
RADIATOR HOSE 209-03-42431

挖掘机配件 Excavator Parts

冷却系统 Cooling System



软管 PC1250-8 PC850-8 RADIATOR
HOSE 209-03-42411



软管 PC2000-8 RADIATOR HOSE
21T-03-32590



软管 PC300-8M0 HOSE
207-01-72391



软管 PC300-8 COOLING HOSE
207-03-76430



软管 PC200-8 RADIATOR HOSE
20Y-03-42250 20Y-03-41141



软管 PC300-7 AIR COOLER
HOSE 6743-11-4961



软管 PC300-8M0 RADIATOR
HOSE 207-03-75640 207-03-72770



软管 PC350-7 RADIATOR HOSE
207-03-71220 207-03-71232



软管 PC300-7 COOLING HOSE
6743-11-4941



软管 PC350-7 AFTERCOOLER
HOSE 6743-11-4931



软管 PC350-7 AFTERCOOLER
HOSE 6743-11-4940



软管 PC350-7 COOLING HOSE
6743-11-4910



软管 PC400-7 COOLING HOSE
6156-11-4480



软管 PC300-7 COOLING HOSE
6743-11-4930



软管 PC300-8 COOLING HOSE
207-01-75270



网 PC200-8 NET 20Y-03-42670
20Y-03-4626



网 PC300-7 NET
207-03-71280



网 PC300-8M0 PC350-8M0 NET
207-03-72261 207-03-72471



冷却器芯 PC300-8 COOLER
CORE 6743-61-2210 (15P)



盖 WA480-6 PC600-8
CAP 416-03-11170

工作装置 Work Equipment

挖掘机配件 Excavator Parts



连杆总成 PC2000-8 LINK ASS'Y
21T-70-00350



连杆总成 PC2000-8 LINK ASS'Y
21T-70-00360



连杆 PC2000-8 PC2000-11
LINK 21T-70-33131 21T-70-33151



连杆 PC2000-8 PC2000-11
LINK 21T-70-33161



连杆 PC2000-8
LINK 21T-70-33141



连杆总成 PC220-8 LINK ASS'Y
206-70-00830



连杆总成 PC300-8 LINK ASS'Y
207-70-73110



连杆总成 PC400-8 LINK ASS'Y
208-70-00750



连杆总成 PC200-8 LINK ASS'Y
20Y-70-01240



连杆 PC200-8 LINK
205-70-73130



连杆 PC220-8 LINK
206-70-57120



连杆 PC300-8 LINK
207-70-33120



连杆 PC400-8 LINK
208-70-73610 208-70-73120



衬套 PC850-8 BUSHING
209-944-5230



衬套 PC1250-8 BUSHING
707-46-14010



衬套 PC200-8 BUSHING
20Y-70-31512



衬套 PC220-8 BUSHING
206-70-71272



衬套 PC300-8 BUSHING
207-70-71162



衬套 PC300-8 BUSHING
207-70-72460



衬套 PC400-8 BUSHING
208-70-71510

挖掘机配件 Excavator Parts

工作装置 Work Equipment



衬套 PC2000-8 BUSHING
21T-70-73160



衬套 PC2000-8 BUSHING
21T-70-73170



衬套 PC2000-8 BUSHING
209-72-11251



衬套 PC1250-8 BUSHING
21N-70-31181



衬套 PC1250-8 BUSHING
21N-70-32550



衬套 PC1250-8 BUSHING
209-944-5230



销 PC500LC-10M0 LINK PIN
2A8-70-13220



销 PC800 PIN
209-70-57331



销 PC220-8 PIN
205-70-73270



销 PC300-8 PIN
207-70-73210



销 PC400-8 PIN
208-70-61191



销 PC400-8 PIN
208-70-74170




销 PC490LC-10 PIN
208-70-71580



销 PC500LC-10M0 PIN
2A8-70-13230



销 PC500LC-10M0 PIN
2A8-70-D3230



销 PC650LC-8E0 PIN
21M-70-11160



销 PC1250-8
PIN 21N-70-33161



销 PC1250-8
PIN 209-70-71331



座 PC300-8 SEAT
205-62-73431



座 PC300-8 SEAT
205-62-73430

护罩和门 Work Equipment

挖掘机配件 Excavator Parts



左侧门 PC200-8 COVER 20Y-54-71136
20Y-54-77250



左侧门 PC220-8M0 COVER
206-54-25290



右侧门 PC300-7 COVER
207-54-71322



左侧门 PC300-7
COVER 207-54-71342



空滤门 PC200-8 COVER
20Y-54-71144 206-54-21261



空滤门 PC300-7 COVER
207-54-71332



空滤门 PC300-8 COVER
207-54-78830



右侧门 PC210-10 COVER
20Y-54-57220



电瓶箱总成 PC200-8
CASE ASS'Y 20Y-54-74103




电瓶箱总成 PC300-7
CASE ASS'Y 20Y-54-66101



电瓶箱总成 PC400-7
CASE ASS'Y 208-54-71422



PC200-7 底护板
UNDER COVER



PC360-7底护板
UNDER COVER



PC400-8 底护板
UNDER COVER



隔板 PC200-8 MAIN
CONTROL VALVE PARTITION
20Y-54-76470 20Y-54-72331



隔板 PC200-8 MAIN PUMP
PARTITION 20Y-54-73850 72481
73770 71561



隔板 PC300-8
PUMP SIDE PARTITION
207-54-73721 74330 73730 73741



隔板 PC400-8
MAIN VALVE PARTITION
208-54-78670 77270 78410



隔板 PC400-8
PARTITION (MACHINE CAB)
208-54-77980 77210 71840



隔板 PC400-8
PUMP SIDE PARTITION
208-54-77221 77240 77250

挖掘机配件 Excavator Parts

护罩和门 Work Equipment



隔板 PC300-7 PUMP SIDE
PARTITION 207-54-72612
72662 72541 72552



隔板 PC300-7
MAIN VALVE PARTITION
207-54-72511 73850 72581



立柱 PC200-8 PC220-8
PCHB215LC-1 FRAME



立柱 PC300-7
PC350-7 FRAME



立柱 PC300-8M0
PC350-8M0 FRAME



立柱 PC400-8 PC450-8
PC500LC-8 FRAME



支架 PC200-8 BRACKET
20Y-53-12564



支架 PC300-7 BRACKET
208-53-12561



支架 PC200-8 BRACKET
20Y-54-75930



支架 PC300-8 BRACKET
208-54-71920



后视镜 PC60-8 WA200-6
MIRROR 419-06-27130



后视镜 PC210-10 MIRROR
2A5-54-13420



后视镜 PC300-8 MIRROR
207-54-75710



后视镜 PC300-7 MIRROR
08174-13118 20Y-54-28911



后视镜 PC300-8 MIRROR
20Y-54-74280



后视镜 WA480-6 PC450-8
MIRROR 421-54-25610



锁 PC-7-8 LOCK (WELDED)
20Y-54-71372



锁 PC200-8M0 LOCK (WELDED)
20Y-54-25852 20Y-54-77120



锁 PC300-8 LOCK ASS'Y
20Y-54-73190



锁 PC300-8 LOCK ASS'Y
20Y-54-77130

矿山机械底盘件 Mining machinery parts

挖掘机配件 Excavator Parts



涨紧油缸 PC200-8
CUSHION ASSEMBLY



涨紧油缸 PC220-8 CUSHION
ASSEMBLY 206-30-00070



涨紧油缸 PC220-8M0 CUSHION
ASSEMBLY 206-30-00090



涨紧油缸 PC300-7 CUSHION
ASSEMBLY 207-30-00390



涨紧油缸 PC350-8M0 CUSHION
ASSEMBLY 207-30-00970



引导轮 PC200-8 IDLER ASS'Y
20Y-30-00442



引导轮 PC800 FRONT IDLER
ASS'Y 209-30-0001



引导轮 E345D IDLER ASS'Y
248-7151



支重轮 PC450-8 TRACK ROLLER
208-30-00210 208-30-00310



支重轮 PC500-10 TRACK ROLLER
208-30-00464



支重轮 CAT345B CAT349 TRACK
ROLLER 1787293



支重轮 CAT390 TRACK ROLLER
1855065



支重轮 CAT E325 E329 TRACK
ROLLER 6Y1057



支重轮 Hitachi ZX450 TRACK
ROLLER YA00005142 4633629



支重轮 R520 TRACK ROLLER
81E7-00663



支重轮 ZAXIS ZX360 TRACK
ROLLER 9253782 9247454



支重轮 SY335 SY365 SY375
TRACK ROLLER



支重轮 SANY SY550 SY485 SY500
TRACK ROLLER



支重轮 XCMG XE900 XE950
TRACK ROLLER



托轮 PC200-8 PC220-8 CARRIER
ROLLER 20Y-30-00481

挖掘机配件 Excavator Parts

矿山机械底盘件 Mining machinery parts



托轮 Kobelco SK200 CARRIER
ROLLER FKS2003000-N



托轮 PC200-7 CARRIER
ROLLER 22U-30-00021



托轮 PC500-10M0 CARRIER
ROLLER 208-30-00483



链轮 PC400-8 SPROCKET
208-27-31221 208-27-61210



链轮 CAT325 SPROCKET
6Y4898



链轮 CAT365 CAT374
SPROCKET 1419655



链轮 CAT345 CAT349 SPROCKET
6Y5685



链轮 LG950 SPROCKET



链轮 EX200 SPROCKET
1018740 10211239



链轮 PC300-8 SPROCKET
207-27-61210 207-27-71460



链轮 SK330-8 SK350
SPROCKET LC51D01008P1



加注阀 VALVE 07959-20001



护板 PC200 TRACK FRAME IDLER
AND CUSHION PLATE (WELDED)



护板 PC300-7 PC300-8 GUARD
207-30-77110 77120 77130 77140



护板 PC450-8 TRACK FRAME
(GUARD) 208-30-77110
77120 77130 77140



护板 PC450-8 TRAVEL PIPING
GUARD 208-30-75311 75321
75332 75342 75351 75361 58230



护板 PC200-8 GUARD
20Y-30-31160



护板 PC300 TRACK FRAME IDLER
AND CUSHION PLATE (WELDED)



护板 PC300-8 GUARD
207-30-51191



护板 PC400-8 GUARD
208-30-61190

过滤器 filters

挖掘机配件 Excavator Parts



水分离器 PC2000-8 HD785-7
WATER SEPARATOR
600-311-9330



水分离器 PC228US-3
WATER SEPARATOR
22U-04-2113



通气阀 PC1250-11 BREATHER
208-60-21152



通气阀 PC300-8 BREATHER
20Y-60-42250



进气管 PC130-8 HOSE
203-01-12111



进气管 PC200-7 HOSE
20Y-01-31151



进气管 PC200-8 HOSE
20Y-01-41110



进气管 PC200-8E0 HOSE
205-01-31131



进气管 PC220-7 HOSE
206-01-61111



进气管 PC220-8M0 HOSE
20Y-01-41911



进气管 PC300-7 HOSE
207-01-72110



滤清器 PC200-8 AIR CLEANER
ASS'Y 6738-81-7210



滤清器 PC200-8M0 AIR
CLEANER ASS'Y 6738-81-7510



滤清器 PC300-7 CLEANER
ASSEMBLY 6743-81-7901



滤清器 PC400-7 AIR CLEANER
ASS'Y 6156-81-7210



预滤器 PC200-11M0 CLEANER
ASSEMBLY 2A5-01-21250



预滤器 PC300-8M0 CLEANER
ASSEMBLY 21N-01-31330



过滤器 PC300-8 FILTER ASS'Y
20Y-62-51681



过滤器 PC300-8 STRAINER
20Y-60-31140



过滤器 PC400-8 STRAINER
07069-25400



过滤器 PC78US-8 ELEMENT
21W-60-41121



过滤器 PC200-7 ELEMENT
207-60-71182



过滤器 PC300-8 ELEMENT
207-60-71183



过滤器 PC400-8 ELEMENT
208-60-71124 208-60-71123



过滤器 STRAINER
22B-60-11160



过滤器 PC300-8 STRAINER
207-60-61250



过滤器 PC1250-7 ELEMENT
21N-62-31221



过滤器 PC2000-8 FILTER
ASS'Y 209-60-79100



滤芯 FILTER 20Y-62-51691



滤芯 CARTRIDGE
6736-51-5142



滤芯 PC450-8 CARTRIDGE
600-311-3841 600-319-3841



滤芯 PC450-8 CARTRIDGE
600-311-4510 600-319-4540



滤杯 PC200-8 FILTER BOWL
600-311-3640



滤杯 PC200-8MO FILTER BOWL
600-311-5641



滤杯 PC500-10 FILTER BOWL
600-311-5440



滤杯 PC1250-8 FILTER BOWL
600-311-3220



滤网 D375A-5 FILTER
723-56-33660



滤网 D475A-5 FILTER
708-2L-25480



滤网 PC300-8 FILTER
702-21-53120



滤网 D475A-5 FILTER
723-40-82220



修理包 主泵 PC200-8 MAIN
PUMP SEAL KIT P2008-KIT-P1



修理包 主阀 PC200-8
MAIN VALVE SEAL P2008-KIT-V1



修理包 主阀 PC300-7 MAIN VALVE
SEAL P3007-KIT-V1



修理包 主阀 PC300-8MO MAIN
VALVE SEAL KIT P3008-KIT-V1



修理包 主阀 PC56-7 MAIN
VALVE SEAL KIT P0567-KIT-V1



修理包 主阀 PC200-7 MAIN
VALVE SEAL P2007-KIT-V1



修理包 主阀 PC200-8MO MAIN
VALVE SEAL KIT P2008MO-KIT-V1



修理包 主阀 PC400-7 MAIN
VALVE SEAL KIT P4007-KIT-V1



修理包 主泵 PC200-8 PUMP
CARBON RING SEAL SERVICE
KIT P2408-KIT-P8



修理包 主阀 PC200-8 VALVE
CARBON RING SEAL SERVICE
KIT P2408-KIT-V8



修理包 主阀 PC300-7
VALVE CARBON RING SEAL
SERVICE KIT P3607-KIT-V8



修理包 主泵 PC300-8 PUMP
CARBON RING SEAL SERVICE
KIT P3608-KIT-P8



修理包 主泵 PC56-7 MAIN PUMP
SEAL KIT P0567-KIT-P1



修理包 回转马达 SWIVEL JOINT
SEAL SERVICE KIT SJ-PC200-7



修理包 涨紧油缸 PC200-8
CUSHION SERVICE KIT



修理包 涨紧油缸 PC400-8
CUSHION SERVICE KIT



密封 PC1800 PC2000 PACKING
21T-30-14210



密封 PC1800 PC2000 PACKING
21T-30-14220




密封 PC2000-8 SEAL
21T-30-14230 (Cold Area
Arrangement (-30 deg C))



耐磨环 HD785 PC2000 WEAR RING
07155-02045

挖掘机配件 Excavator Parts

服务套件&密封件 Service kit and Seals

			
密封 PC1100 PC1250 SEAL 21N-30-14180 FOR	密封 PC1250-7 O-RING 07000-12105	密封 PC1250-8 SEAL 21N-30-14180	密封 WA420-3 FRONT SEAL 6742-01-1770
			
环 PC1250-7 RING 707-44-20910	密封 HD465-7 HM400-2 SEAL 721-47-12020	密封 PC300-8 PC450-8 SEAL 207-25-61161	密封 PC360-7 D375 SEAL 702-16-71150
			
O型圈 O-RING 07000-A5165	O型圈 O-RING 07000-A5185	O型圈 O-RING 07000-B1009	O型圈 O-RING 07000-B2011
			
垫圈 D375 WA480 GASKET 07005-01212	卡环 PC70-8 D20A-8 SNAP RING 04064-03515	卡环 PC70-8 PC78UU-6 SNAP RING 201-30-71310	卡环 PC110-8M0 PC130-8 SNAP RING 04077-00075
			
卡环 PC220-8 PC228US-1 SNAP RING 04077-00085	卡环 PC220-8 WA420-3 SNAP RING 04064-04518	卡环 PC400-8 WA380-3 D155AX-5 SNAP RING 04064-07525	卡环 PC1250-7 WA470-3 SNAP RING 04064-06525

螺栓螺母 Bolt and Nut

挖掘机配件 Excavator Parts

			
螺栓 D155 PC2000-8 ROLLER BOLT 156-70-12250	螺栓 D155AX-6 TRACK SHOE BOLT 176-32-11210	螺栓 D375A-5 TRACK ROLLER BOLT 01011-62710	螺栓 PC750 PC800 TRACK FRAME BOLT 209-09-51110
			
螺栓 D375 BOLT 195-71-52280 17M-71-21530	边盖螺栓 PC200-8 BOLT 20Y-27-13281	边盖螺栓 PC300-7 PC300-8 BOLT 01011-61880	边盖螺栓 PC300-8M0 BOLT 01011-61890
			
螺栓 PC200-8 ENGINE MOUNT BOLT 20Y-01-12270	螺栓 PC350-8 SPROCKET BOLT 207-27-51311	支承螺栓 PC200-8 SWING CIRCLE BOLT 20Y-25-11290	支承螺栓 PC220-8 SWING CIRCLE BOLT 206-25-61110
			
支承螺栓 PC350-8 SWING CIRCLE BOLT 207-25-75120	支承螺栓 PC350-8 SWING CIRCLE BOLT 208-25-31160 207-25-75110	支承螺栓 PC400-8 SWING CIRCLE BOLT 207-25-31180 21N-04-41410	支承螺栓 PC400-8 SWING CIRCLE BOLT 208-25-71231
			
支承螺栓 PC500LC-8 SWING CIRCLE BOLT 208-25-41181	支承螺栓 PC500LC-8 SWING CIRCLE BOLT 208-25-41190	支承螺栓 PC650-8 SWING CIRCLE BOLT 21M-25-11170	支承螺栓 PC650-8 SWING CIRCLE BOLT 01011-83090



放水阀 PC300-8 VALVE
07700-50345



放水阀 PC300-8 VALVE
07700-50455



连接 D85ESS-2 END
04252-21061



连接 JOINT 20Y-43-12180



接头螺栓 PC300-8 JOINT BOLT
6732-71-5620



接头螺栓 PC2000-8 SAA12V140E-3
JOINT BOLT 6215-11-6560



接头螺栓 WA380-3 JOINT BOLT
6732-71-6510



螺栓 SAA6D170E SA12V140
BOLT 01435-00635



螺栓 BOLT 01010-81225



螺栓 BOLT 01024-80825
01010-80825



螺栓 BOLT 01024-81030
01010-81030



螺栓 BOLT 01252-60635



螺塞 D85EX-15R D155AX PUMP
PLUG 708-8E-16150



螺塞 PC78US-8 PLUG
TZ810B2021-00 TZ410D1033-01



螺塞 PC400-7 PLUG
20Y-27-31190



螺栓 SOLENOID VALVE BOLT
NY81416-05010



管夹 KOMATSU CLIP
04434-51408 04434-50610



黄油嘴 FITTING 07020-00000



黄油嘴 FITTING 07020-00675



黄油嘴 grease gun single
handle Coupler



风扇马达 D85EX-15 MOTOR ASS'Y
708-7S-00352



电磁阀 D155AX-6 SOLENOID
VALVE 209-60-77290



先导阀 D155AX-8 PILOT VALVE
702-21-6220



先导阀 D155AX-6 PILOT VALVE
702-21-57600



共轨总成 D275 D375 COMMON RAIL
6261-71-1220



喷油器 D155 INJECTOR ASS'Y
6261-11-3200



喷油器 D275 INJECTOR ASS'Y
6261-11-3100



喷油器 D375A INJECTOR ASS'Y
6245-11-3100



齿轮 D475A-5 GEAR
198-27-45162



关节 D475A-5 JOINT
198-71-31380



垫圈 D375A-6 GASKET
6743-11-3230



阀总成 D85 D155 VALVE
09482-10000



蓄能器 D61EX ACCUMULATOR
425-62-23751



线束 D375A-6 WIRING
HARNESS 6245-81-9130



线束 D375A-5 WIRING HARNESS
6240-81-9130



线束 D155AX-6 SAA6D140E-5
WIRING HARNESS
6261-81-9280



传感器 D155 FUEL PRESSURE
SENSOR ND499000-6160



传感器 D155AX-5 PRESSURE
SENSOR 7861-92-1610



传感器 D475A-5 TEMPERATURE
SENSOR 7861-93-3510



传感器 D68ESS-12 SENSOR
7861-92-3320




传感器 D375A-2 ENGINE
REVOLUTION SENSOR
7861-92-2340



传感器 D375 REVOLUTION
SENSOR 7861-93-2330



传感器 D475 SENSOR
20Y-979-6191



燃油油位计 D475A-3 FUEL LEVEL
SENSOR 7861-92-4930



传感器 指示器 D155 INDICATOR
08672-01000



水位传感器 D375A-3 WATER
LEVEL SENSOR 7861-92-4520



TC转速传感器 D375A-5
TACHOMETER SENSOR
7861-93-2220



传感器 D155AX-5 TEMPERATURE
SENSOR 7861-92-3410



倒车报警器 D85ESS-3 D155A-6
BACKUP ALARM 22U-06-27671



倒车报警器 D375 BACKUP
ALARM 20Y-06-41812 D1910



灯 D375A-6 WORK LAMP
ASS'Y 426-06-31810



注油泵开关 D85EX-18 PRIMING
PUMP SWITCH 600-815-9780



盖 D155 D475 CAP
07092-01000



盖 D37A CAP 104-03-41230



限压阀 D85EX LIMITER
ND095420-0440



连接器 D65EX-16 CONNECTOR
6745-71-6130



硬管 D65EX-16 FILTER TUBE
6745-61-8140



硬管 D65EX-16 FILTER TUBE
6745-61-8130



硬管 D65EX-18 TUBE
6745-71-5690



硬管 D85 D155 TUBE
ND446260-2160



螺栓 D155AX-5 FINAL DRIVE
COVER BOLT 01010-62055



螺栓 D275 SAA6D140E-5
JOINT BOLT 6934-72-7190



螺栓 D375 BOLT 195-27-33130
& 195-27-33141



螺栓 D375 D475 BOLT
07206-30710



卡箍 D155A-6 CLAMP
14Y-21-13190



卡箍 D155A-6 COUPLING
14Y-21-13210



螺栓 D475A-5 BIT BOLT
198-71-21870



螺栓 D475A-5 TRACK ROLLER
BOLT 19M-09-12850



压力传感器 D375 D475 PRESSURE
SENSOR 7861-93-1670



盖总成 D475 HEAD ASS'Y
6219-71-6700



转速传感器 D85EX-18 D375A-6
Revolution Sensor 729-11-41000



转速传感器 SENSOR,PICK-UP
TACHOMETER 7861-92-2330

隆瑞配件商城

Longrui mall store

自卸车配件 Dump trucks parts

LONGRUI
济宁隆瑞机械有限公司



阀总成 HD785-7 EPC
VALVE ASS'Y 56B-43-12402



阀总成 HD465-7
VALVE ASS'Y 569-43-83140



阀总成 HD605-8
SHUT OFF VALVE 42C-60-18230



加注阀 HD785 ACCUMULATOR
CHARGE VALVE 561-43-8A220



切断阀 HD605 FRONT BRAKE
CUT VALVE ASS'Y 569-43-83160



比例阀 HD605-7 HD785-7 VALVE,
PROPORTIONAL 569-43-83171



电机总成 Hd785-7
MOTOR ASS'Y 421-62-32700



紧急转向装置 HD785-7 Emergency
Steering Assembly 561-40-80200



开关 HD785 HD605 TIMER
SWITCH 600-815-9472



灯 HD785 LAMP ASSEMBLY
566-06-6A310 566-06-6A320



灯 HM350-2 HM400-2
LAMP ASS'Y 417-06-23320



线束 HD465-7 HD605-7
WIRING HARNESS 569-15-55820



传感器 HD785-7 PRESSURE
SENSOR 7861-93-1620



传感器 HD785-7 SENSOR
7861-93-4520




开关 HD405-6 HD785-5
SWITCH ASS'Y 7861-92-5701



保险丝 HD405 FUSE, 25AMP
423-Z93-6341



传感器 HD785-7 SENSOR
7861-93-4550



传感器 HD785-7 BLOWBY SENSOR
ASS'Y 6218-81-4111



传感器 HD785-7 DUST INDICATOR
600-815-8860



传感器 HD785-7 PRESSURE SWITCH
418-43-37681



油位传感器 HD605-7 SENSOR,
FUEL LEVEL 569-06-83410



开关 HD785-7 PRESSURE SWITCH
421-43-32912



压力开关 HM400-2 PRESSURE
SWITCH 418-43-37230



垫 HD785-7 CUSHION
287-01-18340



垫 HD785-7 CUSHION
569-01-81130



水壶 HD325-6 HD405-7 TANK
566-03-6E110



转向柱 HD785-7 HD605-7
COLUMN ASS'Y 569-40-83300



制动盘 HD405-6 HM400-2
DISC, BRAKE 425-33-11510



放水阀 HD785-7 VALVE
561-04-82121



阀 HM400-2 HD785-7 VALVE
56B-43-17340



垫 HD785-7 HD465-7 CUSHION
569-14-41130



车窗开关 HD785-7 POWER
WINDOW SWITCH 426-56-21490

轮式装载机配件 Wheel loader parts



轮式装载机配件 Wheel loader parts



油缸 WA500-3 CYLINDER ASS'Y
707-01-03243



轴承 WA380-6 BEARING ASS'Y
423-20-15113



轴承 WA470-6 BEARING ASS'Y
421-20-15123



齿轮 WA380-6 DIFFERENTIAL GEAR
423-22-31480



壳体 WA380-6 DIFFERENTIAL
CASE ASS'Y 423-22-31503



马达 WA470-6 MOTOR ASSEMBLY
708-75-00550



传动轴总成 WA800-3 WA900-3
DRIVE SHAFT ASS'Y 427-20-12211



传动轴 WA320-6 PROPELLER
SHAFT 418-20-32190



传动轴 WA380-6 PROPELLER SHAFT
423-20-39210



摩擦片 WA380-6 DIFFERENTIAL
DISK 56D-22-27410



摩擦板 WA380-6 DIFFERENTIAL
PLATE 56D-22-27451



传感器 WA470-3 WATER
LEVEL SENSOR 7861-92-4500



传感器 WA320-6 SENSOR
418-06-36210



传感器 WA470-6 SENSOR, FUEL
LEVEL 7861-93-4832



传感器 WA470-6 WA600-6 SENSOR,
TEMPERATURE 426-06-31120



传感器 WA600-8 PRESSURE
SENSOR 7861-93-1870



传感器 WA500-8 WA900-3
SENSOR 7861-92-1950



开关 WA470-6 SWITCH,
PRESSURE 421-43-32912



开关 WA500 SWITCH
421-43-22912



开关 WA500-6 SWITCH
421-43-32922

轮式装载机配件 Wheel loader parts



传感器 WA500-8 WA900-3
SENSOR, TORQUE CONVERTER
OIL FILTER 7861-92-1950



油位传感器 WA600-3 SENSOR,
FUEL LEVEL 7861-92-4831



开关 WA380-6 TRANSMISSION
SWITCH 417-43-26212



灯 WA380-6 LAMP
424-06-43211



灯 WA200-6 LAMP
11Y-06-11372



灯 WA500-6 LAMP
424-06-D3220



灯 WA500-8 TURN SIGNAL LAMP
424-06-43221



过滤器 WA420 FILTER ASS'Y
419-15-14800



滤芯 WA470-6 CARTRIDGE
714-07-28713



维修套件 WA380-5 DUMP CYLINDER
SERVICE KIT 707-99-64540



维修套件 WA380-6 SERVICE KIT
707-99-41100



维修套件 WA380-5 LIFT CYLINDER
SERVICE KIT 707-99-64080



维修套件 WA380-6 SERVICE KIT
707-99-48620



维修套件 WA380-6 SERVICE KIT
707-99-41100



维修套件 WA380-6 SERVICE KIT
707-99-56620



蓄能器 WA600-8 ACCUMULATOR
425-62-23751



轴 WA800-3E0 WA900-3
SHAFT 427-46-12410



衬套 WA800-3E0 WA900-3
BUSHING 427-46-12440



衬套 WA800-3E0 WA900-3
BUSHING 427-46-12450



轨距 WA600 GAUGE
09289-10000